



525 First St.
Farmington, MN 55024
Phone: 651-463-BASE (2273)
Toll Free: 866-391-6216
Fax: 651-463-2320
Email: info@base-spec.com
Website: www.base-spec.com

Cleaning & Maintenance Instructions

Aluminum Roll-up Mats

General

- During the winter season, remove roll-up mats and clean rails once per week. During other seasons, once per month should be sufficient.
- Each time you clean the rails, make sure there are no residues or particles under the mats. This will prevent roll-up mats from warping due to an uneven substrate and prevent long-term problems. Vacuuming is the most effective method for this cleaning.
- If the units are above a drain, ensure that nothing is blocking the water flow to the drain.
- Debris between the rails should be removed during the cleaning process. This will ensure the rails remain straight and work properly.
- **Never apply wax** or other polishing products to the surface of the mats; this would create a slippery surface that could cause slips and falls.

Specifics

- Clean aluminum top surfaces with a soapy solution and leave to dry.
- If applicable, depending on insert option chosen, periodically clean carpet and scraping inserts with a hot water extraction machine to remove soil and restore pile.

Optional accessories

- When cleaning roll-up mats outfitted with aluminum or rubber hinges, inspect the hinges and lock mechanism to ensure that all parts are securely attached and are functioning properly. All latches should be inspected and greased with water resistant grease. Any unit not functioning properly should be replaced to avoid further problems.